

The Recommended Spare Parts for 6 Cylinder Diesel Engine

6缸柴油机建议备用件

1、★ The marked spare parts should be replaced according to wear and damage; 2、▲ The marked spare parts can be stocked for every 4-5 sets; 3、Please replace the lubricating oil and coolant strictly according to the operating instructions.

1、带★标记的配件视磨损、损坏情况更换; 2、带▲标记的配件可按每4-5台机器备货; 3、润滑油和冷却液请严格按照使用说明书更换。

Description	中文	Qty/Set	Qty/Set	50-100h	500h	1000h	2500h	5000h
Oil filter	机油滤芯	Pcs	1	1	3	6	10	20
Fuel filter	燃油滤芯	Pcs	1	1	2	3	5	10
Air filter	空滤芯	Pcs	1		1	2	4	8
Belt	皮带	Pcs	1		1	2	4	6
Cylinder head gasket	汽缸垫	Pcs	1			1	2	4
Head cover gasket	汽缸盖罩密封垫	Pcs	1		1	3	6	8
Oil seal-air gate	气门导管密封圈	Pcs	12		12	12	24	48
Front oil seal	前油封	Pcs	1			1	2	4
Rear oil seal	后油封	Pcs	1			1	2	4
Paper gasket kit	全车垫(纸)	Pcs/Set	1				1	1
Thermostat	节温器★	Pcs	1			1	1	2
Cylinder liner	汽缸套	Pcs	6			6	6	12
Piston ring	活塞环★	Pcs/Set	1			1	1	2
Piston	活塞★	Pcs	6				6	12
Piston pin	活塞销★	Pcs	6				6	12
Connecting rod bush	连杆小头衬套★	Pcs	6				6	12
Rod bearing shell	连杆轴承瓦★	Pcs/Set	1				1	1
Main bearing shell	曲轴轴承瓦★	Pcs/Set	1				1	1
Fuel pump	喷油泵总成▲	Pcs	1				1	1
Injector	喷油器总成▲	Pcs	6			6	6	6
Oil pump	机油泵总成▲	Pcs	1				1	1
Turbocharger	涡轮增压器▲	Pcs	1				1	1
Water pump	水泵▲	Pcs	1			1	1	2
Start motor	起动机▲	Pcs	1			1	1	2
Alternator	发电机▲	Pcs	1			1	1	2
Water temperature sensor	水温传感器▲	Pcs	1			1	1	2
Oil pressure sensor	机油压力传感器▲	Pcs	1			1	1	2